

# LS183 Spectrum Transmission Meter

User Manual V5.1

Please read this manual carefully before using and reserve it for reference.



### I. Product Introduction

The instrument is able to simultaneously measure and display UV, VL and IR transmission values. This meter is self-contained light sources and self-calibration. No adjustment is needed. The users only need plug the power supply, turn on the switch and put the sample in the opening. The resulting performance data appear on the display.

#### II. Parameter

Size: 216mm \*134mm \*29mm (L\*H\*W)

2. Testing opening: Wide 47mm \* Height 91mm

3. Weigh: 590g

4. Sample thickness: < 47mm

5. Resolution: 0.1%

6. Accuracy: ±2%(Colorless and transparent material)

7. UV peak wavelength: 365nm


8. VL wavelength: 380nm - 760nm, conforming to the CIE photopic luminosity function

9. IR Peak wavelength: 940nm

10. Power supply: 5V DC Adapter

#### III. Structure

- "OFF/ON", Power Switch.
- "USB", the type-C power socket.
- "Display1, Display2, Display3", dial switch for three different display interfaces.



# IV. Meter Operation

#### 1. Power on self-test




Plug the power supply, keep the testing opening empty, turn on the switch, wait for the meter to self-test, when the self-test is successful, three "100%" will show on the LCD. If self-test failed, the following reasons for failed "Self-test":

- a) Testing sample in the testing opening during Meter powering on.
- b) Ambient Light too strong.
- c) Too much dust in the testing hole, please clean the dust with air duster gun.
- d) Equipment damage, need to send back to the factory repair.



#### 2. Measurement

Place sample into the testing opening to measure the performance characteristics. Refer to the following picture demonstrations.





## V. Feature

- 1. UV transmission meter, IR transmission meter, light transmittance meter. Three function in ONE device.
- 2. Self-calibration and auto-calibration, NO need any manual adjustments.
- 3. Simple operation, putting the testing sample in the opening, UV, VL and IR transmission values of the sample will simultaneously display.

# VI. Packing list

No.	Description	Quantity	Unit
1	Spectrum Transmission Meter	1	pcs
2	DC5V Adapter	1	pcs
3	User Manual	1	pcs
4	Certificate / warranty card	1	pcs

# VII. Service

- 1. The meter has one-year warranty. If the meter works abnormally, please send the whole meter to the company for maintenance.
- 2. Provide users with spare parts and lifelong maintenance services.
- 3. Provide the users with the meter inspection service for free.
- 4. Free technical support for long term.

Manufacturer: Shenzhen Linshang Technology Co.,Ltd.

Website: www.linshangtech.com Service hotline: 086-0755-86263411 Email: sales21@linshangtech.com